3/16 SQ

3/16" SQ

1/4 x 1/2 SPAR

1/4 x 1/8" SPAR DOUBLER

ASSEMBLE SPARS BEFORE STARTING WING CONSTRUCTION

HARDWOOD SERVO RAILS

KRAFT SERVO

6 TAP HOLE WITH 6-40 ATTACH BELLCRANK BY THREADING ON SCREW

6-40 x 1" RD HEAD

1/4 x 1/2 x 1/8 HARDWOOD (BELLCRANK MOUNT)

HALLCREST BELLCRANK TAPPED 6-40

1/2 x 1/8 HARDWOOD INSERT

"BOTTOM VIEW OF WING"

1/8" SHEET RIBS

(MALTESE CROSS ON BOTTOM OF WING)

BLACK

WHITE

1/4" RIB

1/4" SHEET

FEATHER

1/8 x 2"

SOFT BALSA BLOCK

AILERON 1/4" x 1 1/2 x 36"

3/4 x 3/16

1/8 x 3/16

3/4 x 3/16

3/4 x 3/16

BALSA TIP STRIP

COVER TOP & BOTTOM WITH 1/16 SHEET

ELEVATOR 1/4 SHEET

VECO 45

1" T.E. STOCK

3/4 x 3/4 x 1/8 HDWOD BLOCK

F1

JENSEN STEERING ARM

1/16" PLY EPOXIED TO COWL

FIBER GLASS COWL

F2

F4

F5

F6

BLACK

WHITE

AILERON SERVO

ELEVATOR SERVO

RUDDER SERVO

WILLIAMS BROTHERS PILOT

SCRAP SILK SCARF

3/16" SQ SPACE

1/4 x 1/2" DOUBLER SPAR AT CENTER

1/8 THONG

1/2 DOWEL

3/8 x 1/2 x 2

1/4 SHEET HATCH

1/16 PLY

1/8 DOWEL GLUED TO SIDES @ F2

FZ 9 x 3 1/2

TOP FLUSH NYLON BEARINGS

JENSEN NOSE GEAR ASSEMBLY

F3

BRAKE TUBING

WASHER (SOLDERED)

KRAFT SERVOS

10-32 x 3/8" SCREWS

1/16 PLY

1/2 PLYWOOD BOTTOM END PIECE

1/4 DOWELS

CUTOUT IN FUSELAGE SIDES TO ALLOW WOOD ARM MOVEMENT

1/8 DOWELS

F2 1/8 SHEET

F4 1/8 SHEET

1/8 SHEET

F5 3/16" SHEET

F6 3/16 SHEET

3/32 SHT

CUT FROM 3/16" SHEET

1/8 SHEET RUDDER

1/16 x 3/16

3/16 x 1"

COVER BOTH SIDES WITH 1/16" SHEET

3/16" SCRAP

3/4 x 3/16"

3/16" SHEET

1/2 OF 3/16" HDWOOD DOWEL

1/16" SQ SCRAP BALSA CEMENTED ON BOTH SIDES OF BASE OR FLOOR TO BOTTOM OF FUSELAGE

WHEEL BRAKES (1 LH & 1 RH REQ'D)

FLAT PATTERN FOR MAIN LANDING GEAR (.5/32" CAST DURAL)

MADE FROM SCRAP ALUMINUM OR BRASS

BRAKE CABLE

FLATTENED BRASS TUBING SOLDERED TO BENT WIRE

DESIGNED BY PHIL KRAFT
DRAWN BY GEO WALKER